



CAMMJET Bulletin

Print – Laminate – Cut Procedure Documentation

First and most important - this feature can only be used with a piece of media. It will not work if either "roll" or "edge" are selected at the time of set-up.

- 1) Set ColorChoice 3.0 to "Print Only" in the setup.
- 2) Set "Print Crop Marks" in the driver setup.
- 3) Send the job to the printer – print only.
- 4) Feed some excess material out of the machine (approx 4-5 inches) and cut sheet.
- 5) Laminate/Treat media.
- 6) Load the piece of media in the CAMMJET.
- 7) Turn on the unit - but do not press "Set-Up".
- 8) Move the blinking cursor over so that it is blinking on "Piece"
- 9) Once the cursor is on Piece, press "Base Point".
- 10) "Auto Crop Mark" will appear on the display, with "Base Align" under it.
- 11) Press "Enter" to enable the crop mark function - The unit will then perform the automatic crop mark sensing.
- 12) The CAMMJET will then be ready to receive the cut data.
- 13) Set ColorChoice 3.0 to "Cut Only" in the setup.
- 14) Send the data to the machine.

If you have any problems performing this procedure, please contact Roland Technical support department. (800) 542-2307. Thank you for choosing Roland.